



## **OWNER'S MANUAL JWL-1442VS Wood Lathe**



708358K Shown

### **WMH TOOL GROUP**

Consumer/Light Industrial Products Division  
P.O. BOX 1349  
Auburn, WA 98071-1349  
Ph: 1-800-274-6848 • Fax: 1-800-274-6840  
E-mail: [jet@wmhtoolgroup.com](mailto:jet@wmhtoolgroup.com)  
[www.wmhtoolgroup.com](http://www.wmhtoolgroup.com)

**M-708358 09/02**  
Copyright © WMH Tool Group

This manual has been prepared for the owner and operators of a JWL-1442VS. Its purpose, aside from machine operation, is to promote safety through the use of accepted correct operating and maintenance procedures. Completely read the safety and maintenance instructions before operating or servicing the machine. To obtain maximum life and efficiency from your wood lathe, and to aid in using the machine safely, read this manual thoroughly and follow instructions carefully.

### **Warranty & Service**

The WMH Tool Group warrants every product it sells. If one of our tools needs service or repair, one of our Authorized Repair Stations located throughout the United States can give you quick service.

In most cases, any one of these WMH Tool Group Repair Stations can authorize warranty repair, assist you in obtaining parts, or perform routine maintenance and major repair on your JET, Performax, Wilton, or Powermatic tools.

For the name of an Authorized Repair Station in your area, please call 1-800-274-6848, or visit [www.wmhtoolgroup.com](http://www.wmhtoolgroup.com)

### **More Information**

Remember, the WMH Tool Group is consistently adding new products to the line. For complete, up-to-date product information, check with your local WMH Tool Group distributor, or visit [www.wmhtoolgroup.com](http://www.wmhtoolgroup.com)

### **WMH Tool Group Warranty**

The WMH Tool Group (including Performax, JET, Wilton and Powermatic brands) makes every effort to assure that its products meet high quality and durability standards and warrants to the original retail consumer/purchaser of our products that each product be free from defects in materials and workmanship as follow: 1 YEAR LIMITED WARRANTY ON ALL PRODUCTS UNLESS SPECIFIED OTHERWISE. This Warranty does not apply to defects due directly or indirectly to misuse, abuse, negligence or accidents, normal wear-and-tear, repair or alterations outside our facilities, or to a lack of maintenance.

THE WMH TOOL GROUP LIMITS ALL IMPLIED WARRANTIES TO THE PERIOD SPECIFIED ABOVE, FROM THE DATE THE PRODUCT WAS PURCHASED AT RETAIL. EXCEPT AS STATED HEREIN, ANY IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS ARE EXCLUDED. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG THE IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE WMH TOOL GROUP SHALL IN NO EVENT BE LIABLE FOR DEATH, INJURIES TO PERSONS OR PROPERTY, OR FOR INCIDENTAL, CONTINGENT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OF OUR PRODUCTS. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

To take advantage of this warranty, the product or part must be returned for examination, postage prepaid, to an Authorized Repair Station designated by our office. Proof of purchase date and an explanation of the complaint must accompany the merchandise. If our inspection discloses a defect, we will either repair or replace the product, or refund the purchase price if we cannot readily and quickly provide a repair or replacement, if you are willing to accept a refund. We will return repaired product or replacement at WMH Tool Group's expense, but if it is determined there is no defect, or that the defect resulted from causes not within the scope of WMH Tool Group's warranty, then the user must bear the cost of storing and returning the product. This warranty gives you specific legal rights; you may also have other rights which vary from state to state.

The WMH Tool Group sells through distributors only. Members of the WMH Tool Group reserve the right to effect at any time, without prior notice, those alterations to parts, fittings, and accessory equipment which they may deem necessary for any reason whatsoever.

## **WARNING**

1. **Read and understand the entire owner's manual before attempting assembly or operation.**
2. **This wood lathe is designed and intended for use by properly trained and experienced personnel only. If you are not familiar with the proper and safe operation of a wood lathe, do not use until proper training and knowledge have been obtained.**
3. Always wear approved safety glasses/face shields while using this machine.
4. Make certain the machine is properly grounded.
5. Before operating the machine, remove tie, rings, watches, other jewelry, and roll up sleeves above the elbows. Remove all loose clothing and confine long hair. Do **not** wear gloves.
6. Keep the floor around the machine clean and free of scrap material, oil and grease.
7. Keep machine guards in place at all times when the machine is in use. If removed for maintenance purposes, use extreme caution and replace the guards immediately.
8. Do **not** over reach. Maintain a balanced stance at all times so that you do not fall or lean against blades or other moving parts.
9. Make all machine adjustments or maintenance with the machine unplugged from the power source.
10. Use the right tool. Don't force a tool or attachment to do a job that it was not designed for.
11. Replace warning labels if they become obscured or removed.
12. Make certain the switch is in the **OFF** position before connecting the machine to the power supply.
13. Give your work undivided attention. Looking around, carrying on a conversation, and "horse-play" are careless acts that can result in serious injury.
14. Keep visitors a safe distance from the work area.
15. Use recommended accessories; improper accessories may be hazardous.
16. Read and understand warnings posted on the machine and in this manual.
17. Failure to comply with all of these warnings may cause serious injury.
18. Some dust created by power sanding, sawing, grinding, drilling and other construction activities contains chemicals known to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:
  - Lead from lead based paint
  - crystalline silica from bricks and cement and other masonry products, and
  - arsenic and chromium from chemically-treated lumber.
19. Your risk from those exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specifically designed to filter out microscopic particles
20. Do not operate tool while under the influence of drugs, alcohol or any medication.
21. Keep tools sharp and clean for safe and best performance. Dull tools can grab in the work and be jerked from the operator's hands causing serious injury.
22. Check the condition of the stock to be turned. Make sure it is free of knots, warpage, checked ends, improperly made or cured glue joints and other conditions which can cause it to be thrown out of the lathe.
23. Securely fasten spur/live centers to the material being used.

24. Check centers and center sockets in the headstock and tailstock to be sure they are free of dirt or rust and oil lightly before inserting centers.
25. Test each set-up by revolving the work by hand to insure it clears the tool rest and bed. Check setup at the lowest speed before increasing it to the operating speed.
26. Use the correct cutting tool for the operation to be performed and keep all tools in a sharpened condition.
27. Use low speeds for roughing and for long or large diameter work. If vibration occurs, stop the machine and correct the cause. See speed recommendations.

Diameter of Work	Roughing RPM	General Cutting RPM	Finishing RPM
Under 2"	1500	3000	3000
2 to 4"	600	1500	2300
4 to 6"	450	1100	1500
6 to 8"	450	600	1100
8 to 10"	450	600	850
10 to 12"	450	600	850
12 to 14"	450	450	600

28. When sanding, remove the tool rest from the machine, apply light pressure, and use a slow speed to avoid heat build up.
29. When turning large diameter pieces, such as bowls, always operate the lathe at low speeds. See speed recommendations.
30. Do not attempt to engage the spindle lock pin until the spindle has stopped. If leaving the machine area, turn it off and wait until the spindle stops before departing.
31. Make no adjustments except speed change with the spindle rotating and always disconnect machine from power source when performing maintenance to avoid accidental starting or electrical shock.
32. Provide for adequate surrounding work space and overhead non-glare lighting.
33. When stopping the lathe, never grab the part or face plate to slow it down. Let the work coast to a stop.
34. Use only JET factory authorized replacement parts and accessories; otherwise the warranty and guarantee are null and void.
35. Do not use this JET wood lathe for other than its intended use. If used for other purposes, JET disclaims any real or implied warranty and holds itself harmless from any injury that may result from that use.

## Grounding Instructions

**Caution:** This tool must be grounded while in use to protect the operator from electric shock.

In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This tool is equipped with an electric cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.

Do not modify the plug provided. If it will not fit the outlet, have the proper outlet installed by a qualified electrician.


Improper connection of the equipment-grounding conductor can result in a risk of electric shock. The conductor, with insulation having an outer surface that is green with or without yellow stripes, is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.

Check with a qualified electrician or service personnel if the grounding instructions are not completely understood, or if in doubt as to whether the tool is properly grounded. Use only three wire extension cords that have three-prong grounding plugs and three-pole receptacles that accept the tool's plug.

Repair or replace a damaged or worn cord immediately.

### 115 Volt Operation

As received from the factory, your lathe is ready to run at 115 volt operation. This lathe, when wired for 115 volt, is intended for use on a circuit that has an outlet and a plug that looks like the one illustrated in (A). A temporary adapter, which looks like the adapter as illustrated in (B), may be used to connect this plug to a two-pole receptacle, as shown in (B) if a properly grounded outlet is not available. The temporary adapter should only be used until a properly grounded outlet can be installed by a qualified electrician. **This adapter is not applicable in Canada.** The green colored rigid ear, lug, or tab, extending from the adapter, must be connected to a permanent ground such as a properly grounded outlet box, as shown in (B).



## 230 Volt Operation

If 230V, single-phase operation is desired, the following instructions must be followed:

1. **Disconnect the machine from the power source.**
2. This lathe is supplied with four motor leads that are connected for 115V operation, as shown in Figure A. Reconnect these four motor leads for 230V operation, as shown in Figure B.
3. The 115V attachment plug (A), supplied with the lathe, must be replaced with a UL/CSA listed plug suitable for 230V operation (D). Contact your local Authorized JET Service Center or qualified electrician for proper procedures to install the plug. The lathe must comply with all local and national codes after the 230 volt plug is installed.
4. The lathe with a 230 volt plug should only be connected to an outlet having the same configuration (D). No adapter is available or should be used with the 230 volt plug.

**Important:** In all cases (115 or 230 volts), make certain the receptacle in question is properly grounded. If you are not sure, have a registered electrician check the receptacle.




FIGURE A






FIGURE B



## Introduction

The JET JWL-1442VS lathe you have purchased is a high quality tool that will give you years of superior service. You will get maximum performance and enjoyment from your new lathe if you would take a few moments now to review the entire manual before beginning assembly and operation.

The JET JWL-1442VS, as well as all JET products, is backed by a nationwide network of authorized distributors and/or service centers. Please contact your nearest distributor should you require parts or service. Parts are also available directly from JET by calling 1-800-274-6848.

## Table of Contents

Warranty.....	2
Warnings .....	3-4
Grounding Instructions.....	5
115V Operation.....	5
230V Operation .....	6
Introduction.....	7
Table of Contents.....	7
Specifications .....	8
Contents of the Shipping Container.....	9
Unpacking and Cleanup.....	9
Assembly.....	9
Stand Legs (optional accessory) .....	10
Stand Shelf .....	10
Controls and Features .....	10-12
Lathe Tools .....	12-13
Mounting Workpiece Between Centers.....	13
Stock Selection.....	14
Roughing Out .....	14
Beads, Coves, "V" Cuts and Parting.....	15
Sanding & Finishing.....	16
Face Plate or Bowl Turning .....	16
Mounting Stock.....	16
Face Plate or Chuck .....	17
Wood Selection.....	17
Checks and Cracks.....	17
Distortion .....	17
Tools for Bowl Turning.....	17
To Shape Outside of Bowl .....	18
To Shape Interior of Bowl .....	19
Sanding and Finishing .....	19
Adjusting Clamping Mechanism .....	20
Changing the Belt and Bearings.....	20
Troubleshooting .....	21
Part Breakdowns and Part's List .....	22-27
Wiring Diagram.....	28

Specifications

JWL-1442VS

Stock Number.....	708358
Over Bed .....	14"
Swing Over Tool Rest Base .....	10"
Distance Between Centers.....	42"
Speeds (RPM) .....	450, 600, 850, 1100, 1500, 1900, 2300, 3000
Spindle Nose .....	1" x 8 T.P.I.
Drive Spindle Through Hole .....	3/8"
Tailstock Spindle Through Hole.....	3/8"
Tailstock Spindle Travel .....	4"
Tool Rest.....	12"
Face Plate .....	6"
Headstock Rotation .....	45°, 90°, 135°, 180°, 270°, 360°
Headstock Taper .....	MT-2
Tailstock Taper .....	MT-2
Spindle Center to Floor (approx.) .....	43-1/2"
Motor .....	1 HP, 1Ph
.....	115V/230V, <b>Prewired 115V</b>
Net Weight (approx.).....	200 Lbs.
Shipping Weight (approx.).....	215 Lbs.



708358K Shown

The specifications in this manual are given as general information and are not binding. WMH Tool Group reserves the right to effect, at any time and without prior notice, changes or alterations to parts, fittings, and accessory equipment deemed necessary for any reason whatsoever.





## WARNING

Read and understand the entire contents of this manual before attempting assembly or operation!

Failure to comply may cause serious injury!

### Contents of the Shipping Containers

1. Lathe
1. Tailstock
1. Headstock
1. Face Plate
1. Tool Rest Body
1. Accessory Package
1. Owner's Manual & Warranty Card

### Accessory Package Box

1. Live Center
1. Spur Center
1. Index Pin
1. Wrench
1. Drift Rod
1. Tool Rest
1. Tool Rest Extension

### Unpacking and Clean-Up

1. Remove the shipping container. Do not discard any shipping material until the lathe is set up and running properly.
2. Remove tailstock, tool rest and headstock before lifting, see "Adjusting Clamping Mechanism" on Page 20 on how to remove the tailstock, headstock or tool rest.
3. Remove hex cap bolts from skid bottom and lift the lathe bed, with the help from another person, off the skid and into position.
4. Mount the lathe to a solid workbench or refer to the "Stand Legs (optional assembly)" instructions, on page 10, if you have purchased the stand legs.
5. Clean all rust protected surfaces with a cleaner degreaser. Clean under the headstock, tailstock and tool rest body.
6. Reinstall headstock, tool rest and tailstock unless you are mounting to optional legs.

### Assembly

1. Secure tool rest (A, Fig. 1) to tool rest body (B, Fig. 1) by tightening handle (C, Fig. 1).  
**Note:** You may need to assemble the tool rest extension between the tool rest body and tool rest for certain turning applications.



708358K Shown with optional legs



Contents of Accessory Package



Fig. 1

### Stand Legs (optional accessory)

1. At this point the headstock, tailstock and tool rest should be removed. With help from another person lift the lathe bed and place onto a workbench.
2. Angle lathe bed so that stand leg mounting holes are accessible, see Figure 2.
3. Thread adjustable feet (A, Fig. 2) into stand leg (B, Fig. 2). There is a flat spot on the shaft near the foot that will accommodate a wrench. Thread a hex nut (C, Fig. 2) onto shaft and leave loose for now.
4. Mount the leg to lathe bed with four 5/16" flat washers and four 5/16"-18 x 1-1/2" hex socket cap screws (D, Fig. 2).
5. Repeat for the other leg.
6. Adjust the feet so that the lathe rests evenly on the floor, and tighten the nuts.
7. Reinstall headstock, tailstock and tool rest.




Fig. 2

### Stand Shelf

You can make an extra shelf that rests between the legs if you wish, see Figure 3. It will be useful for storing lathe accessories, or adding sand bags for some extra weight. The two 2x4's should be 55-3/4" long. The plywood should be ripped into two equal pieces 27-13/16"L x 17"W so that it can be assembled between the legs. Use screws to attach the plywood to the 2x4 supports.




Fig. 3

### Controls & Features

- E. **Headstock Lock Handle:** (E, Fig. 4)  
Locks the head in position. Unlock the handle to position the head in any location along the lathe bed. Tighten handle when properly positioned.
- F. **Headstock Indexing Pin:** (F, Fig. 4)  
Turn the knurled knob counter-clockwise to unlock the plunger. Pull the knob out to release the headstock. Unlock the headstock locking handle and rotate the headstock. Turn knurled knob clockwise until it stops to lock plunger.




Fig. 4

- G. **Headstock Spindle Lock:** (G, Fig. 5)  
Push in pin to keep the spindle from turning.

**CAUTION!**  
Never press the headstock spindle lock while the spindle is turning!

- H. **Headstock On/Off Switch:** (H, Fig. 5)  
Flip the switch up to turn "ON" the lathe. Flip the switch down to turn the lathe "OFF".
- I. **Headstock On/Off Switch Key:** Remove key (I, Fig. 5) when in the "OFF" position. The switch will not work until key is reinstalled.
- J. **Headstock Speed Selector:** (J, Fig. 5)  
Place handle directly above the desired RPM speed. Pull handle out and move to the desired speed, see Figure 6.

**CAUTION!**  
Only change speeds while the spindle is turning!

- K. **Headstock Faceplate:** (K, Fig. 7)  
Used for turning bowls. There are a number of screw holes for mounting the workpiece. Thread the faceplate onto the spindle in a clockwise direction, and tighten two set screws. Remove the faceplate by loosening two set screws. Push in headstock spindle lock and use the provided wrench on faceplate flats.
- L. **Headstock Spur Center:** (L, Fig. 7)  
Used for turning between centers. Spindle taper is MT-2. Remove spur center by inserting drift rod through the opposite end of the spindle and knocking spur center out.
- M. **Headstock Indexing Hole:** (M, Fig. 7)  
Thread indexing pin into the indexing hole making sure that it locates in the spindle hole. There are 12 holes in the spindle 30° apart. There are three holes in the headstock casting that accept the indexing pin. These holes are 20° apart. The combination of holes will allow you to mark your workpiece for evenly spaced features.

**CAUTION!**  
Never start the lathe with the index pin engaged in the spindle!




Fig. 5

Diameter of Work	Roughing RPM	General Cutting RPM	Finishing RPM
Under 2"	1500	3000	3000
2 to 4"	600	1500	2300
4 to 6"	450	1100	1500
6 to 8"	450	600	1100
8 to 10"	450	600	850
10 to 12"	450	600	850
12 to 14"	450	450	600

Fig. 6




Fig. 7

- N. **Tool Rest Body Lock Handle:** (N, Fig. 8)  
Locks the tool rest body in position. Unlock handle to position the tool rest in any location along lathe bed. Tighten handle when properly positioned.
- O. **Tool Rest Lock Handle:** (O, Fig. 8)  
Locks the tool rest in position. Unlock the handle to position tool rest at a specific angle, or height. Tighten handle when properly positioned.
- P. **Tailstock Lock Handle:** (P, Fig. 9)  
Locks the tailstock in position. Unlock handle to position the tool rest in any location along lathe bed. Tighten handle when properly positioned.
- Q. **Tailstock Quill Lock Handle:** (Q, Fig. 9)  
Locks the tailstock quill in position. Unlock handle to position the quill. Tighten handle when properly positioned.
- R. **Tailstock Quill Handwheel:** (R, Fig. 9)  
Turn the handwheel to position the quill. The tailstock quill lock handle must be loose to position quill.
- S. **Tailstock Live Center:** (S, Fig. 9)  
Used for turning between centers. Quill taper is MT-2. Remove live center by retracting the quill until live center loosens.



Fig. 8




Fig. 9

## Lathe Tools

If possible, select only high quality, high speed steel turning tools with long handles. As one becomes proficient in turning, a variety of specialty tools for specific applications can be acquired. The following tools provide the basics for most woodturning projects. See your JET distributor for a wide variety of JET woodturning tools.

**Roughing Gouge** - used for rapidly cut raw wood into round stock, see Figure 10.

**Deep Fluted Bowl Gouge** - used for turning bowls and plates, see Figure 10.

**Spindle Gouge** - used for turning beads, coves and other details, see Figure 10.

**Spear** - fine scraping and delicate operations, such as the forming of beads, parallel grooves and shallow vees, etc, see Figure 10.




Fig. 10

## Lathe Tools (continued)

**Skew** - used to make vees, beads, etc., see Figure 11.

**Square Scraper** - used for diameter scraping and featureless scraping, etc, see Figure 11.

**Large Domed Scraper** - used to reduce ridges on the interior of bowls, round edges of bowls, etc, see Figure 11.

**Parting Tool** - used to cut directly into the material, or to make a cut off. Also used for scraping and to set diameters, see Figure 11.

For safety and best performance, **keep tools sharp**. If a tool stops cutting, or requires excessive pressure to make a cut, it needs to be sharpened. A number of brand name sharpening jigs and fixtures are available, however, a woodturner should learn to sharpen tools freehand.

## Mounting Workpiece Between Centers

Spindle turning takes place between the centers of the lathe. It requires a spur center in the headstock and a live center in the tailstock.

1. With a ruler locate and mark the center on each end by going corner to corner, see Figure 12. Accuracy is not critical on full rounds but extremely important on stock where square sections are to remain. Put a dimple in each end of the stock with an awl or nail.
2. Extremely hard woods may require kerfs cut into the spur drive end of stock, see Figure 12. You may need to drive the spur center into the stock with a wood mallet. **Note:** Never drive stock onto spur while it is mounted in the lathe spindle.
3. Install workpiece by inserting the attached spur center into the spindle taper on the headstock.
4. Bring tailstock into position, lock it to the bed, and advance quill with the handwheel in order to seat the live center into the workpiece. Lock the quill in place. Make sure the live center point is centered on your mark.

5. Move tool rest into position. It should be parallel to workpiece, approximately at the centerline, and approximately 1/8" from the closest part of the workpiece. Lock tool rest body and tool rest in place.
6. Rotate workpiece by hand to check for proper clearance from tool rest. **Note:** You may want to trim off the corners of a square workpiece to make turning a little easier.
7. Start lathe at **lowest** speed and bring it up to the appropriate RPM for the size of stock, see Figure 6 page 11.

The position of the tool rest can be varied to suit the work and operator. After you become experienced with setting tool rest changing the position will become second nature for the workpiece and comfort of the user.




Fig. 11




Fig. 12

## Stock Selection

Stock for spindles should be straight grained and free of checks, cracks, knots and other defects. It should be cut 1/8" to 1/4" larger than the finished diameter and may require additional length to remove ends if required. Larger stock should have the corners removed to produce an octagon making the piece easier to rough down to a cylinder, see Figure 13.

## Roughing Out

1. Use a large roughing gouge and begin cutting about 2" from the tailstock end of the workpiece. Place the tool on the tool rest with the heel of the tool on the surface to be cut.
2. Slowly and gently raise tool handle until cutting edge comes into contact with the workpiece. Work to the right towards the end of the workpiece. You never want to start at the end of a workpiece.
3. Now continue to work the rest of the workpiece. Roll the flute (hollowed-out portion) of the tool in the direction of the cut, see Figure 14. Make long sweeping cuts in a continuous motion to rough the piece down to a cylinder. Keep as much of the bevel of the tool as possible in contact with the workpiece to ensure control and avoid catches. **Note:** Always cut downhill, or from large diameter to small diameter. Always work *toward* the end of a workpiece, never start cutting at the end.
4. Once the workpiece is roughed down to a cylinder, smooth it with a large skew. Place the cutting point near the center of the chisel and high on the workpiece, see Figure 15. Touching one of the points of the skew to the spinning workpiece may cause a catch and ruin the workpiece.
5. Add details to the workpiece with skew, spindle gouge, etc.



Fig. 13



Fig. 14



Fig. 15

## Beads

1. Place parting tool on the tool rest and move tool forward to make the full bevel of the tool come in contact with the workpiece. Gently raise handle to make cut to the appropriate depth.
2. Repeat for other side of the bead.
3. Using a small skew or spindle gouge, start in the center between the two cuts and cut down each side to form the bead. Roll the tool in direction of cut.

## Coves

1. Use a spindle gouge. With the flute of the tool at 90 degrees to the workpiece, touch the center of the cutting edge to the workpiece and roll in towards the bottom of the cove. **Stop at the bottom;** attempting to go up the opposite side may cause the tool to catch.
2. Move the tool over the desired width of the cove.
3. With the flute facing the opposite direction, repeat step 1 for other side of cove. Stop at bottom of cut.

## "V" Cuts

1. Use the long point of the skew. **Note:** Do not press the long point of the skew directly into the workpiece to create the "V"; this will result in a burned, or burnished "V" with fibers being rolled up at both sides.
2. Lightly mark the center of the "V" with the tip of the skew.
3. Move the point of the skew to the right half of the desired width of your cut.
4. With the bevel parallel to the right side of the cut, raise the handle and push the tool in to the desired depth.
5. Repeat from the left side. The two cuts should meet at the bottom and leave a clean "V" cut.
6. Additional cuts may be taken to add to either the depth or width of the cut.

## Parting

1. Place parting tool on tool rest and raise the handle until it starts to cut and continue to cut to the desired depth.
2. If the cut is deep a clearance cut should be made alongside the first cut to prevent the tool tip from burning.




Fig. 16




Fig. 17




Fig. 18

## Sanding & Finishing

Leaving clean cuts will reduce the amount of sanding required. Begin with a fine sandpaper (120 grit or finer). Coarser sandpaper will leave deep scratches that are difficult to remove, and dull crisp details. Fold the sandpaper into a pad; do not wrap sandpaper around your fingers or the workpiece.

To apply a finish, the workpiece can be left on the lathe. Turn off lathe and use a brush, or cloth to apply the finish. Remove excess finish before restarting lathe. Allow to dry and sand again with 320, or 400 grit sandpaper. Apply additional coats of finish and buff.

## Face Plate & Bowl Turning

Face plate turning is normally done on the inboard side of the headstock over the bed see Figure 19. You must pivot the headstock 180° for larger workpieces.

## Mounting Stock

Use of a face plate is the most common method for holding a block of wood for turning bowls, and plates.

1. Select stock at least 1/8" to 1/4" larger than the dimension on the desired finished workpiece.
2. True one surface of the workpiece for mounting against the face plate. It is best to leave extra stock against the face plate that can be cut off when the workpiece is finished.
3. Using the face plate as a template, mark the location of the mounting holes, and drill pilot holes of the appropriate size. If the mounting screws on the face plate interfere with the workpiece, a waste block can be mounted to the face plate and then the waste block mounted to the workpiece by gluing or screwing, see Figure 20.
4. Both waste block and workpiece should have good flat surfaces.
5. Push in on the spindle lock and thread face plate and workpiece onto the spindle. Tighten set screws in the face plate when secure.




Fig. 19




Fig. 20



## **Face Plate or Chuck**

While faceplates are the simplest, most reliable method of holding a block of wood for turning, chucks can also be used. A chuck is not a requirement but is handy when working on more than one piece at a time. Rather than removing screws, you simply open the chuck and change workpieces. The most popular ones are four jaw scroll chucks with a variety of jaws to accommodate different size tenons. Most also come with a screw chuck as well.

## **Wood Selection**

Firewood is the cheapest, most widely available stock to use while learning to turn bowls. Develop skill with each tool before attempting to make a finished piece. It is best to start with dry wood, without worrying about drying or distortion. Once turning becomes comfortable, try green wood which cuts very easily. As the turner gains experience, he or she will find extraordinary grain and figure in the form of burls, crotches and bark inclusions.

## **Checks & Cracks**

Green wood will check and crack. For best results, leave logs in as long lengths as you can handle. As the material starts to dry, surface cracks will develop on the ends of the log. Cut off two to three inches and you should find good, sound wood. Also cut the log in half along the pith to avoid having it in the finished piece. Most checks radiate from the pith. As you turn bowls from green wood, make sure you maintain a consistent wall thickness throughout the piece. Leaving a piece thick in some areas and thin in others will cause the wood to dry unevenly and promote checks and cracks.

## **Distortion**

Distortion is a problem associated with turning green wood. It will vary from one type of wood to the next. Typically, fruitwoods tend to distort more than others. It also varies with the time of year the tree was cut and how the logs are stored.

## **Tools for Bowl Turning**

The deep fluted bowl gouge is the most essential and versatile tool for most bowl and faceplate style turning. The bowl gouge is heavier and easier to control than other types of

gouges. It also allows removal of wood much faster and with less vibration than other gouges. Most average sized bowl work can be accomplished with a 3/8" or 1/2" bowl gouge. A 1/4" bowl gouge is best suited for smaller bowls and light finishing cuts. Larger 3/4" and 1" bowl gouges are only used for extremely large pieces.

Large domed scrapers can also be used to help clean up the interior surfaces of bowls. A light touch with the scraper slightly tilted will eliminate some of the ridges left by a bowl gouge.

## To Shape Outside of Bowl

1. Odd shaped burls, crotches and other irregular shaped blanks require special preparation before mounting in a chuck, or onto a faceplate. Remove the bark, if there is any, from what appears to be the center of the top of workpiece.
2. Drive spur center into the top of workpiece with a wood mallet.
3. Slip spur center into headstock taper and bring the tailstock, with a live center into position. Lock tailstock to bed and advance spindle in order to seat the cup center into workpiece, see Figure 21. Tighten quill lock.
4. Position tool support below the centerline and about 1/4" from the workpiece. **Note:** For larger outboard turning, an optional outboard turning stand is used to place the tool support, see your JET distributor.
5. Turn workpiece by hand to ensure proper clearance.
6. Start lathe at lowest speed and bring it up to the maximum safe speed for the size of work to be turned, see Figure 6 on page 11. If the machine starts to vibrate, lower the speed until vibration stops.
7. Rough out the outside of the bowl with the 1/2" deep fluted bowl gouge, holding the tool firmly against your hip. For best control, use your whole body to move the gouge through the workpiece.
8. As the bowl takes shape, work on the bottom (tailstock end) to accommodate attaching a face plate, see Figure 21.
9. Turn a short tenon (about 1/8" long) the size of the hole in the faceplate, see Figure 21. This will allow centering the workpiece when the faceplate is attached. **Note:** If you plan to use a chuck, turn a tenon of appropriate length and diameter to fit your chuck.
10. Stop the lathe, remove workpiece and attach face plate, or chuck.
11. Finish turning the outside of bowl with 1/2" or 3/8" bowl gouge. Leave additional

material at base of bowl for support while turning interior. This will be removed later.




Fig. 21

## To Shape Interior of Bowl

1. Stop lathe and move tailstock away. Remove center from tailstock to prevent bumping it with elbow.
2. Adjust tool support in front of the bowl just below centerline, at a right angle to the lathe bed.
3. Rotate workpiece by hand to check clearance.
4. Face off top of bowl by making a light shearing cut across the workpiece, from rim to center.
5. Place 1/2" bowl gouge on tool rest at center of the workpiece with the flute facing top of bowl. The tool handle should be level and pointed toward four o'clock, see Figure 22.
6. Use left hand to control cutting edge of gouge, while right hand swings tool handle around toward your body, see Figure 22. The flute should start out facing top of workpiece, and rotate upward as it moves deeper into the bowl to maintain a clean even curve. As tool goes deeper into bowl, progressively work out toward rim. It may be necessary to turn the tool rest into the work piece, as you get deeper into the bowl.  
**Note:** Try to make one, very light continuous movement from the rim to the bottom of the bowl to ensure a clean, sweeping curve through the workpiece. Should there be a few small ridges left, a light cut with a large domed scraper can even out the surface.
7. Develop wall thickness at the rim and maintain it as you work deeper into the bowl. When the interior is finished, move tool support to exterior to re-define bottom of bowl. General rule of thumb: the base should be approximately 1/3 the overall diameter of the bowl.
8. Work the tight area around faceplate or chuck with 1/4" bowl gouge.

Coarser sandpaper tends to leave deep scratches that are hard to eliminate. Use power-sanding techniques to avoid concentric sanding marks around your finished piece. Avoid rounding over the rim and foot with sandpaper. Try to keep details crisp. Finish sanding with 220 grit.

2. Remove sanding dust with tack rags, or compressed air and, with lathe turned off, apply first coat of finish. Let stand for several minutes, wipe off excess. Allow to dry before sanding again with 320 or 400 grit sandpaper.
3. Turn lathe back on and make a separation cut through the base. Stop at about 3" and use a small fine tooth saw to separate the bowl from the waste.
4. Apply additional finish coats and allow to dry before buffing.




Fig. 22

## Sanding and Finishing

1. Remove the tool rest and begin with a fine grit sandpaper (120 grit) and progress through each grit, using only light pressure.

## Adjusting Clamping Mechanism

The clamps are pre-set at the factory and should not need any adjustment. However, if adjustment is needed remove the stud (A, Fig. 23). Loosen the locking handle and slide the headstock, tailstock or tool rest to the edge of the bed and slightly turn the hex nut (B, Fig. 23). Slide back into position and test the handle to make sure it securely locks.

## Changing the Belt and Bearings

Changing belt and bearings can be a difficult task, and should be performed by a JET authorized repair station. Remove headstock and take into a repair station for servicing.

1. Place the belt in its highest speed range. **Do not** change speeds while changing the belt or bearings.
2. Remove the belt cover, and remove the belt from the lower pulley, see Figure 24.
3. Loosen two set screws in the handwheel enough to unthread handwheel (C, Fig. 24).
4. Loosen socket head cap screw enough to unthread the clamping nut (D, Fig. 24).
5. Remove one e-ring (E, Fig. 24) from spindle.
6. Loosen two set screws in the right hand pulley (F, Fig. 24).
7. Use a wood dowel, or aluminum stock to knock spindle towards the tailstock. *Use a material that is softer than the spindle so you do not mushroom end of spindle.* Go only far enough to remove right hand pulley and belt from spindle, see Figure 25 when changing the belt. **Note:** Mark key way on the pulley for easy reference when reassembling.
8. Now you can replace the belt or bearings. There are three bearings #6, 9 and 43 that can be seen in the "Headstock Assembly," page 24.
9. To reassemble reverse the procedure. **Note:** Key way alignment is critical for installment and proper operation. Do not force the pulley. When reinstalling clamping nut thread it on to the spindle until

its snug. Then back off slightly and tighten the socket head cap screw.




Fig. 23




Fig. 24





Fig. 25

## Troubleshooting

Problem	Possible Cause	Solution
Excessive Vibration.	<ol style="list-style-type: none"> <li>1. Workpiece warped, out of round, has major flaw, improperly prepared for turning, or RPM is set too high</li> <li>2. Worn spindle bearings</li> <li>3. Worn belt</li> <li>4. Motor mount bolts loose</li> <li>5. Lathe on uneven surface</li> </ol>	<ol style="list-style-type: none"> <li>1. Correct problem by planing, bandsawing, reduce the RPM, or scrap workpiece all together</li> <li>2. Replace bearings</li> <li>3. Replace belt</li> <li>4. Tighten bolts</li> <li>5. Shim lathe bed, or adjust feet on stand</li> </ol>
Motor or Spindle Stalls or Will not Start	<ol style="list-style-type: none"> <li>1. Excessive cut</li> <li>2. Worn motor</li> <li>3. Broken belt</li> <li>4. Worn spindle bearings</li> <li>5. Improper cooling on motor</li> <li>6. Starting or running capacitor is bad</li> <li>7. Centrifugal switch bad</li> </ol>	<ol style="list-style-type: none"> <li>1. Reduce cut depth</li> <li>2. Replace motor</li> <li>3. Replace belt</li> <li>4. Replace bearings</li> <li>5. Clean sawdust from motor fan</li> <li>6. Replace the starting capacitor</li> <li>7. Replace centrifugal switch</li> </ol>
Motor fails to develop full power.	<ol style="list-style-type: none"> <li>1. Power line overloaded</li> <li>2. Undersize wires in supply system, or extension cord is too long</li> <li>3. Low voltage</li> <li>4. Running capacitor is bad</li> <li>5. Worn motor</li> </ol>	<ol style="list-style-type: none"> <li>1. Correct overload condition</li> <li>2. Increase supply wire size</li> <li>3. Request voltage check from power company and correct low voltage condition</li> <li>4. Replace running capacitor</li> <li>5. Replace motor</li> </ol>
Tools tend to grab or dig in.	<ol style="list-style-type: none"> <li>1. Dull tools</li> <li>2. Tool support set too low</li> <li>3. Tool support set too far from workpiece</li> <li>4. Improper tool being used</li> </ol>	<ol style="list-style-type: none"> <li>1. Sharpen tools</li> <li>2. Reposition tool support height</li> <li>3. Reposition tool support closer to workpiece</li> <li>4. Use correct tool for operation</li> </ol>
Tailstock Moves When Applying Pressure	<ol style="list-style-type: none"> <li>1. Excessive pressure being applied by tailstock. Note: The screw action of the tailstock is capable of applying excessive pressure to workpiece and headstock. Apply only sufficient force by tailstock to hold workpiece securely in place. Excessive pressure can cause damage to machine.</li> <li>2. Lathe bed and tailstock mating surfaces are greasy or oily.</li> </ol>	<ol style="list-style-type: none"> <li>1. Slide tailstock down to the right side of the lathe against the stop. Move headstock into position and apply pressure to workpiece with tailstock.</li> <li>2. Remove and clean surfaces with a cleaner degreaser</li> </ol>

## Bed Assembly




## Parts List for the JWL-1442VS Woodworking Lathe

### Bed Assembly

Index No.	Part No.	Description	Size	Qty.
1	JWL1442-201	Bed		1
2	JWL1442-202	Stud		3
3	JWL1442-124	C-Ring	S19	4
4	TS-0206031	Hex Socket Cap Screw	10-24 x 5/8"	4
5	JWL1442-205	Tool Rest		1
6	JWL1442-206	Tool Support Handle		1
7	JWL1442-207	Tool Support Base		1
8	JWL1442-208	End Cover		1
9	JWL1442-128	Bolt		2
10	JWL1442-210	Tool Support Rod		1
11	JWL1442-211	Handle		1
12	JWL1442-212	Handwheel		1
13	JWL1442-213	Tailstock		1
14	JWL1442-214	Lead Screw		1
15	JWL1442-215	Quill		1
16	JWL1442-216	Live Center		1
17	JWL1442-217	Tailstock Rod		1
18	JWL1442-218	Tailstock Quill Handle		1
19	JWL1442-219	JET Label		1
20	TS-0267021	Set Screw	1/4"-20 x 1/4"	2
21	JWL1442-127	Bushing		2
22	JWL1442-126	Key	5 x 5 x 30	2
23	JWL1442-154	Clamp		2
24	TS-0561081	Hex Nut	3/4"-10	2
25	JWL1442-129	Support Bracket		1
26	JWL1442-226	Extension Tool Rest		1
27	JWL1442-227	Locking Handle		1
	JWL1442-TCA	Tailstock Complete Assembly (not shown)		1
	JWL1442-TRCA	Tool Rest Complete Assembly (not shown)		1

# Headstock Assembly






## Headstock Assembly

Index No.	Part No.	Description	Size	Qty.
1	JWL1442-101	Spur Center	MT2	1
2	JWL1442-102	Face Plate	6"	1
3	JWL1442-103	Spindle		1
4	JWL1442-104	Key	4 x 4 x 80	1
5	JWL1442-105	E-Ring	E-19	1
6	BB-6205ZZ	Ball Bearing	6205ZZ	1
7	JWL1442-107	Headstock		1
8	JWL1442-108	Wave Washer		1
9	BB-6304LLB	Ball Bearing	6304LLB	1
10	JWL1442-110	Lock Nut	3/4"-16	1
11	JWL1442-111	Hand wheel		1
12	TS-0207031	Hex Socket Cap Screw	1/4"-20 x 5/8"	1
13	JWL1442-113	Speed Selector Assembly		1
14	JWL1442-114	Handle		1
15	TS-081C052	Round Head Machine Screw	10-24 x 3/4	2
16	JWL1442-116	Spring		1
17	JWL1442-117	Switch Bracket		1
18	JWL1442-118	Switch Assembly		1
19	TS-081C022	Round Head Machine Screw	10-24 x 3/8"	2
20	TS-081C052	Round Head Machine Screw	10-24 x 3/4"	2
21	JWL1442-121	Bracket		1
22	JWL1442-122	Spindle Lock Pin		1
23	TS-0206031	Hex Socket Cap Screw	10-24 x 5/8"	2
24	JWL1442-124	C-Ring	S19	2
25	JWL1442-125	Lever		1
26	JWL1442-126	Key	5 x 5 x 30	1
27	JWL1442-127	Bushing		1
28	JWL1442-128A	Bolt		1
29	JWL1442-129	Support Bracket		1
30	JWL1442-130	Index Bracket		1
31	TS-0561081	Hex Nut	3/4"-10	1
32	TS-0267021	Set Screw	1/4"-20 x 1/4"	6
33	JWL1442-133	Motor Cord		1
34	JWL1442-134	Key	4 x 4 x 80	1
35	JWL1442-135	Motor	1HP, 1Ph	1
	JWL1442-MF	Motor Fan (not shown)		1
	JWL1442-MFC	Motor Fan Cover (not shown)		1
	JWL1442-CS	Centrifugal Switch (not shown)		1
	JWL1442-CC	Capacitor Cover (not shown)		2
	JWL1442-SC	Starting Capacitor (not shown)	200MFD, 125VAC	1
	JWL1442-RC	Running Capacitor (not shown)	25uF, 250VAC	1
36	JWL1442-136	Switch Box		1
37	JWL1442-137	Spring		1
38	JWL1442-138	Sleeve		1
39	JWL1442-139	C-Ring	S16	1
40	JWL1442-140	Power Cord		1
41	VB-M25	Belt	M-25	1
42	JWL1442-142	Spring		1

Index No.	Part No.	Description	Size	Qty.
43	BB-6006LLB	Ball Bearing	6006LLB	1
44	JWL1442-144	C-Ring	S32	1
45	JWL1442-145	Shifting Lever Bracket		1
46	JWL1442-146	Rack		1
47	JWL1442-147	Strain Relief Bushing		2
48	TS-0207061	Hex Socket Cap Screw	1/4"-20 x 1"	1
49	TS-0561011	Hex Nut	1/4"-20	1
50	JWL1442-150	Pulley Cover		1
51	TS-0081031	Hex Head Bolt	5/16"-18 x 3/4"	2
52	TS-0720081	Lock Washer	5/16"	2
53	JWL1442-153	Plate		1
54	JWL1442-154	Clamp		1
55	JWL1442-155	JET Label		1
56	JWL1442-156	Warning Label		1
57	JWL1442-157	Speed Label		1
58	JWL1442-158	Motor Label		1
59	JWL1442-159	Motor Pulley (left)		1
60	JWL1442-160	Motor Pulley (right)		1
61	JWL1442-161	Spindle Pulley (left)		1
62	JWL1442-162	Spindle Pulley (right)		1
63	TS-081C022	Round Head Machine Screw	10-24 x 3/8"	4
64	JWL1442-164	Knock Out Rod		1
65	TS-081C082	Pan Head Screw	10-24 x 1-1/2"	1
66	JWL1442-166	Clip		1
67	TS-056007	Hex Nut	10-24	2
68	JWL1442-168	Spanner Wrench		1
69	JWL1442-169	Index Pin		1
70	JWL1442-170	Star Washer	3/16"	1
71	JWL1442-171	Hex Socket Cap Screw		1
72	JWL1442-172	Spring		1
73	JWL1442-173	Index Knob		1
74	JWL1442-174	Index Shaft		1
75	JWL1442-175	Spring		1
76	JWL1442-176	Index Bushing		1

## Stand Assembly (optional accessory)




## Stand Assembly (optional)

Index No.	Part No.	Description	Size	Qty.
3.....	JWL1642-203.....	Stand.....		2
5.....	JWL1642-205.....	JET Stripe.....		1
6.....	JWL1642-206.....	Adjustable Foot.....	3/8"	4
7.....	TS-0561031 .....	Hex Nut .....	3/8"	4
9.....	TS-0208081 .....	Hex Socket Cap Screw .....	5/16"-18 x 1-1/2"	8
10.....	TS-0680032 .....	Flat Washer .....	5/16"	8

Wiring Diagram

115V Operation



230V Operation

